## **Laboratory Assessment Preparation List**

<u>General Assessment Guidance</u>: This document is intended to provide guidance for laboratories preparing for an AASHTO re:source On-Site Laboratory Assessment, specifically with regard to the preparation and availability of materials required for demonstration of the test method(s). Preparing for the assessment will improve the efficiency, productivity, and benefit of the assessment for the laboratory.

This document does not address all of the apparatus and procedural requirements which may be evaluated during the assessment. Please consult the applicable AASHTO or ASTM standard for specific requirements. The laboratory may elect to demonstrate the AASHTO, ASTM, or both versions of the test method. The laboratory should be prepared to present required apparatus and to perform the test method in its entirety. Please contact us at (240) 436-4900 if your laboratory has additional questions with regard to preparing for the On-Site Assessment.

<u>AASHTO</u>	<u>ASTM</u>	Asphalt Mixture Assessment Preparation
R30		Have a sample ready to demonstrate mixture conditioning.
R35		Have a record from a mix design. Be prepared to discuss the steps taken in designing the mix and the calculations used. Be prepared to demonstrate all required test methods.
R47		Have a heated sample ready to be reduced. Be prepared to demonstrate one of the three procedures completely.
R59	D1856	Prepare extractant from test method T164/D2172 and to demonstrate the asphalt recovery procedure.
R68	D6926	Prepare to mix a sample and perform the mixing procedure, compaction of the specimen, and testing the specimen. If the laboratory does not mix samples in-house, the sample should be heated to compaction temperature.
Т30	D5444	Prepare an extraction (T164/D2172) or ignition oven (T308/D6307) sample prior to the assessment or retain the sample completed during assessment demonstration. If a previously obtained sample is used, assessors will expect all masses to be recorded for the various stages of the test.
T110	D1461	Pre-heat a hot-mix sample and prepare to demonstrate proper drip rates and perform calculations at the completion of the test.
T164	D2172	Pre-heat a hot-mix sample and prepare to demonstrate the full extraction process and mineral matter determination on all solvent extract. Mineral matter determination can be from a previously obtained sample if the lab retains it in a sealed container and records all data. Gradation analysis of the extracted aggregate is covered separately by test procedures T30/D5444.
T166	D2726	Have a dry, compacted, or cored specimen at room temperature.
T167	D1075 D1074	Prepare to mix a sample and perform the mixing procedure, compaction of the specimen, and testing the specimen. If the laboratory does not mix samples in-house, the sample should be heated to compaction temperature. An additional sample may be previously compacted and moisture conditioned (D1075) or ready to demonstrate the strength testing portion of the procedure.
T168	D979	Have a mix ready to be tested.
T209	D2041	Have a sample ready to be placed in the vacuum bowl. Be able to demonstrate the sample preparation procedures, the vacuuming procedure, the weighing in water or weighing in air procedure, and be capable of completing all calculations at the conclusion of testing.
T245	D6927	Compact a specimen for stability and flow testing prior to the assessment to save cooling time.

OSA.A03-D 1 Revised 2019-03-05

AASHTO	<u>ASTM</u>	Hot Mix Assessment Preparation (Continued)
T246 T247	D1560 D1561	Prepare to mix a sample and perform the mixing procedure and compaction of the specimen. If the laboratory does not mix samples in-house, the sample should be heated to compaction temperature. Prepare stabilometer for testing and calibration.
T269	D3203	The laboratory will not have to prepare a sample. Percent air voids will be calculated from the results of T166/D2726 and T209/D2041 data recorded during the assessment.
T275	D1188	Have a dry, compacted or cored specimen at room temperature. If the lab is running both AASHTO and ASTM, both the AASHTO paraffin and ASTM parafilm procedures must be demonstrated.
T283	D4867	Prepare a minimum of three compacted specimens prior to the assessment, having one for the dry set, one for the freeze-thaw cycle set, and one that is ready to be saturated. All data for percent air voids and saturation should be retained for the assessor's review on the first two specimens.
T287	D4125	Prepare to mix a sample. If the laboratory does not mix samples in-house, heat a specimen to compaction temperature. The standard count procedure and records will also be evaluated. The technician will be required to explain calibration procedures and present corresponding records for the mix being used for testing.
T305	D6390	Have a dry pre-mixed asphalt sample ready to be weighed into the baskets.
Т308	D6307	Have a dry pre-mixed asphalt sample ready to be weighed into the baskets and the oven pre-heated to test temperature. Be prepared to explain correction factor determination procedures and present correction factors determined using the laboratories own oven for the mix being used for testing.
T312	D6925	Prepare to mix a sample. If the laboratory does not mix samples in-house, heat a specimen to compaction temperature.
T324		Have a compacted sample ready to be loaded into the testing machine and a completed test sample ready to be measured.
T329		Have a field or plant produced sample ready to be tested.
T331	D6752	Have a dry, compacted or cored specimen at room temperature. Be prepared to perform all calculations at the completion of the test including correcting for the specific gravity of the plastic bags.
T335	D2950	Have a nuclear gauge available for test demonstration on-site. The assessor will view the standard count determination, as well as backscatter. Ensure a test site area is prepared and available to demonstrate the procedure. If necessary, please coordinate the availability of a field technician to demonstrate the test prior to the assessment. Current gauge calibration records and standard count records will be examined.
	D3549	Have a sample available to measure.
	D3665	Be prepared to discuss stratified-random sampling processes.
	D5404	Prepare extractant from test method T164/D2172 prior to testing.
	D6931	Have a compacted specimen in accordance with one of the specified test methods listed in D6931. Be able to demonstrate measuring, conditioning, and testing of the specimen.
	D7906	Prepare extractant from test method T164/D2172 prior to testing.

OSA.A03-D 2 Revised 2019-03-05

State	Hot Mix Assessment Preparation - Other Methods
CP-L 5106	Prepare to mix a sample and perform the mixing procedure and compaction of the specimen. If the laboratory does not mix samples in-house, the sample should be heated to compaction temperature. Prepare stabilometer for testing and calibration.
CP-L 5115	Prepare to mix a sample. If the laboratory does not mix samples in-house, heat a specimen to compaction temperature.
PTM 702	Pre-heat a hot-mix sample and prepare to demonstrate the full extraction process and mineral matter determination on all solvent extract. Mineral matter determination can be from a previously obtained sample if the lab retains it in a sealed container and records all data.
PTM 715 PTM 716	Have a dry, compacted, or cored specimen at room temperature.
PTM 739	Prepare a sample prior to the assessment or retain the sample completed during assessment demonstration. If a previously obtained sample is used, assessors will expect all masses to be recorded for the various stages of the test.
PTM 757	Have a dry pre-mixed asphalt sample ready to be weighed into the baskets and the oven pre-heated to test temperature.
PTM T209m	Have a sample ready to be placed in the vacuum bowl. Be able to demonstrate the sample preparation procedures, the vacuuming procedure, the weighing in water or weighing in air procedure, and be capable of completing all calculations at the conclusion of testing.
TEX-206-F	Prepare to mix a sample. If the laboratory does not mix samples in-house, heat a specimen to compaction temperature.
TEX-208-F	Prepare to mix a sample and perform the mixing procedure and compaction of the specimen. If the laboratory does not mix samples in-house, the sample should be heated to compaction temperature. Prepare stabilometer for testing and calibration.

OSA.A03-D 3 Revised 2019-03-05